



* The number given in parentheses shows the distance to combustible when titled with insulated flue

**The stove is only suitable for mounting on fire-resistant walls without cracks.*